

Mini Wireless Remote Control Vibrator Reminder With Multiple Vibrations

Application:

This vibrator is a very small electric device that can produce multiple vibrations, it and the transmitter form a remote control vibration kit. When you press different buttons on the transmitter, the vibrator will vibrate different times. They can be use for any kind Silent Reminders occasion, such as magic, reminder, negotiation, nursing, deaf-mute, old man, patient, pet etc.

Feature:

Wireless control.

Small size for easy carrying.

You can control the vibrator by the transmitter (remote control) from any place within a reliable distance.

Wireless RF signal can pass through walls, floors, doors or windows.

Reliable control: The code has thousands of different combinations, and the vibrator only works with the transmitter which use the same code.

One/several transmitters can control one/several vibrators simultaneously.

You can use two or more units in the same place.

Vibrator Parameters:

Model: 0020116 (Z-02)

Working Mode: Multiple Vibrations

Working Frequency: 433.92MHz

Power Supply: 1 x AAA 1.5V Battery (included)

With power switch on the side.

Operating Temperature: -20°C to +70°C

Size: 51mm x 30mm x 14mm

Matching Transmitters:

The vibrator can work with different transmitters, such as model C-4 (100M), CWB-4 (50M, waterproof), CP-4 / CP-8 (500M), CB-4 / CB-6 / CB-8 / CB-12 (1000M) etc. You can set any button of the transmitter to trigger the vibrator to vibrate any number of times.

Working Range:

With a transmitter (such as model C-4) to form a complete set, the maximum working distance can reach 50M in an open ground.

The maximum working distance is a theoretical data, it shall be operated in an open ground, no barriers, no any interference. But in the practice, it will be hindered by trees, walls or other constructions, and will be interfered by other wireless signals. Therefore, the actual distance may not reach this maximum working distance.

If you want to have a further working range, you can use a powerful transmitter, such as CP-4 or CB-4 transmitter.

Usage:

Press a button of the transmitter, the vibrator will vibrate the corresponding times.

Such as,

Press the button 1 of the transmitter, the vibrator vibrates once.

Press the button 2 of the transmitter, the vibrator vibrates twice.

Press the button 3 of the transmitter, the vibrator vibrates three times.

.....

Press the button 11 of the transmitter, the vibrator vibrates eleven times.

Press the button 12 of the transmitter, the vibrator vibrates twelve times.

And so on.

Note: You can set any button of the transmitter to trigger the vibrator to vibrate any number of times.

How to pair the transmitter to the vibrator:

1) Turn on the power switch of the vibrator, and the vibrator vibrates once.

2) If you want to set the button 1 for 1 times of vibration: Press the learning button once in the vibrator, and the vibrator vibrates once. Then press the button 1 on the transmitter, if the vibrator again vibrates once, it means learning is successful.

3) If you want to set the button 2 for 2 times of vibration: Press the learning button twice in the vibrator, and the vibrator vibrates once. Then press the button 2 on the transmitter, if the vibrator again vibrates once, it means learning is successful.

4) If you want to set the button 3 for 3 times of vibration: Press the learning button three times in the vibrator, and the vibrator vibrates once. Then press the button 3 on the transmitter, if the vibrator again vibrates once, it means learning is successful.

5) If you want to set the button 4 for 4 times of vibration: Press the learning button four times in the vibrator, and the vibrator vibrates once. Then press the button 4 on the transmitter, if the vibrator again vibrates once, it means learning is successful.

6) If you want to set the button N for X times of vibration: Press the learning button X times in the vibrator, and the vibrator vibrates once. Then press the button N on the transmitter, if the vibrator again vibrates once, it means learning is successful.

Delete all transmitters:

We have learned the transmitter to the vibrator. If you don't want the vibrator to work with the transmitter, you can delete all codes of the transmitters, which are stored in the vibrator.

Operation: Press and hold the learning button in the vibrator for about 6 seconds until the vibrator stops vibration; then release the learning button. This means all stored codes have been deleted successfully.

