



1 Button Waterproof Desktop Wireless Calling Button / Transmitter

Remote control calling system is the hi-tech electronic product which is integrated wireless communication and computer technology. It includes calling button and calling receiver. Each system have one calling receiver and many calling buttons. When there is a calling from a calling button, calling receiver will display corresponding number.



Changing battery

- (1) Put the screwdriver into the disassemble port and push it up.
- (2) Take out the upper part of the caller from the bottom
- (3) Pull out the battery cover to change the battery.

