

Wall mounting 4 Buttons Waterproof Wireless Calling Button / Transmitter

Remote control calling system is the hi-tech electronic product which is integrated wireless communication and computer technology. It includes calling button and calling receiver. Each system has one calling receiver and many calling buttons. When there is a calling from a calling button, calling receiver will display corresponding number.

It is widely applied to restaurants, coffee shops, karaoke rooms, discos, sauna rooms, beer houses, pubs, night clubs, bowling alleys, golf courses, video halls, hotels, hospitals, schools, chain stores ,shops...

Package Include:

1×Wireless Calling Button

1×23A-12V battery

Parameters:

Transmitting Frequency: 433.92MHz

Working Voltage: 1 x 23A-12V battery

Working Current: 17mA

Coding Type: Learning code

Remote Control Distance: 500m /1500ft (theoretical data in the open field)

Waterproof Case

Case Material: Plastic

Case Color: Red

Case Size: 66mm*63mm*24mm

Usage:


Stick the calling button to wall or desk. When you press its button, the calling receiver will display the corresponding number and make sounds.

Order: When you need to take order, you can press this button.

Call: When you need general calling, you can press this button.

Pay: When you need checkout calling, you can press this button.

Cancel: Press this button the cancel previous calling.



Changing battery

(1) Put the screwdriver into the disassemble port and push it up.

(2) Take out the upper part of the caller from the bottom

(3) Pull out the battery cover to change the battery.

