

## RF Wireless Remote Control Radio Controller / Transmitter & Receiver

### Package Include:

1 x Receiver: S2PX-DC12 / S2PX-DC24 (2 Channel / Four Control Mode)  
2 x Transmitter: C-2  
1 x User manual

### Feature:

Wireless control, easy to install

With high power of 30A

Direct dc power output; control Lights, Motors, Fans, electrically operated Doors / Locks / Windows / Blinds / Cars or Other Appliances.

You can turn on/off the receiver with transmitter (remote control) from any place within a reliable distance; the wireless RF signal can pass through walls, floors and doors.

With characteristics of reverse power protection and over current protection

Audible / visual indication

Use microcontroller model of EM78P156, an 8-bit microprocessor designed and developed with low-power and high-speed CMOS technology.

One/several transmitters can control one/several receivers simultaneously.

Two or more transmitter & receivers set can be used in the same place.

Transmitting Frequency: 315MHz / 433MHz

### Receiver:

Model No.: S2PX-DC12 / S2PX-DC24

Channel: 2 CH

Control Modes: Toggle, Momentary, Latched, Momentary + Toggle

Coding Type: Fixed code or learning code

Coding Setting: By learning

Power Supply (Operating Voltage): DC12V±1V (S2PX-DC12), DC24V±1V (S2PX-DC24)

Output: DC12V (S2PX-DC12), DC24V (S2PX-DC24)

PCB Size: 137mm x 80mm x 25mm

Case Size: 150mm x 90mm x 45mm

Static Current: ≤6mA

Maximum Working Current: 30A / each channel

### Transmitter:

Model No.: C-2

Channel: 2 CH

Remote Control Distance: 100m / 300ft (theoretically)

Encode: Fixed code by Soldering

Unit size: 58mm x 39mm x 16mm

Power Supply: 1 x 23A -12V battery (included, can be used for 12 months)

### Usage:

Setting different control modes (We have set the receiver as Toggle control mode before delivery. If you want to use other control modes, do as following):

1) Setting control mode Toggle: Only connect Jumper-2.

Press button 1: Turn on the relay 1, terminal OUTPUT 1 outputs DC power.

Press button 1 again: Turn off the relay 1, terminal OUTPUT 1 no output.

Press button 2: Turn on the relay 2, terminal OUTPUT 2 outputs DC power.

Press button 2 again: Turn off the relay 2, terminal OUTPUT 2 no output.

2) Setting control mode Momentary: Only connect Jumper-1.

Press and hold button 1: Turn on the relay 1, terminal OUTPUT 1 outputs DC power.

Release button 1: Turn off the relay 1, terminal OUTPUT 1 no output.

Press and hold button 2: Turn on the relay 2, terminal OUTPUT 2 outputs DC power.

Release button 2: Turn off the relay 2, terminal OUTPUT 2 no output.

3) Setting control mode Latched: Do not connect Jumper-1 and Jumper-2.

Press button 1: Turn on the relay 1, terminal OUTPUT 1 outputs DC power.

Turn off the relay 2, terminal OUTPUT 2 no output.

Press button 2: Turn on the relay 2, terminal OUTPUT 2 outputs DC power.

Turn off the relay 1, terminal OUTPUT 1 no output.

4) Setting control mode Momentary + Toggle: Connect Jumper-1 and Jumper-2.

Control mode Momentary (Channel 1):

Press and hold button 1: Turn on the relay 1, terminal OUTPUT 1 outputs DC power.

Release button 1: Turn off the relay 1, terminal OUTPUT 1 no output.

Control mode Toggle (Channel 2):

Press button 2: Turn on the relay 2, terminal OUTPUT 2 outputs DC power.  
Press button 2 again: Turn off the relay 2, terminal OUTPUT 2 no output.

We have learned remote control to the receiver. If you don't want the receiver to work with the remote control, you can delete all codes of remote controls, which are stored in the receiver.

Operation: Press and hold the button of receiver until signal LED flashes slowly; release the button, LED keeps slow flash. That means all stored codes have been deleted successfully.

Learning the button of remote control:

- 1) Press the button of receiver; signal LED on the receiver keeps shining. The receiver enters into status of LEARNING.
- 2) Press any one button on remote control. If signal LED flashes quickly 15 times and turns off, it means learning is successful.
- 3) When receiver is in the status of LEARNING, press again the button of receiver, signal LED turns off, learning process will be discontinued.
- 4) The receiver can learn several remote controls with different codes.

### Application Circuit

